

Compatible Machines

| Description | ID | Footnote |
|--|------|----------|
| - | 82A4 | |
| 100w AMD G3-82HY - 100w Gen 3 | 82HY | |
| 100w AMD G3-82J0 - 100w Gen 3 | 82J0 | |
| 14e Chrome G2-82M1 - 14e Chromebook Gen 2 | 82M1 | |
| 14e Chrome G2-82M2 - 14e Chromebook Gen 2 | 82M2 | |
| 14w G2-82N8 - 14w Gen 2 | 82N8 | |

| | | |
|---|------|--|
| 14w G2-82N9 - 14w Gen 2 | 82N9 | |
| 300w AMD G3-82J1 - 300w Gen 3 | 82J1 | Only support Power bank charging model, not support power pass-through model |
| 300w AMD G3-82J2 - 300w Gen 3 | 82J2 | Only support Power bank charging model, not support power pass-through model |
| C13 Yoga G1 Chromebook- 20UX MT 2020 | 20UX | |
| C13 Yoga G1 Chromebook- 20UY MT 2020 | 20UY | |
| E14 2nd Generation-20TA MT 2020 | 20TA | Only support Power bank charging model, not support power pass-through model |
| E14 2nd Generation-20TB MT 2020 | 20TB | Only support Power bank charging model, not support power pass-through model |

| | | |
|---|------|--|
| E14 2nd Generation-ARE- 20T6 MT 2020 | 20T6 | |
| E14 2nd Generation-ARE- 20T7 MT 2020 | 20T7 | |
| E14 AMD 3rd Generation- 20Y7 - E14 AMD Gen 3 | 20Y7 | Only support Power bank charging model, not support power pass-through model |
| E14 AMD 3rd Generation- 20YD - E14 AMD Gen 3 | 20YD | Only support Power bank charging model, not support power pass-through model |
| E14 AMD 3rd Generation- 20YE - E14 AMD Gen 3 | 20YE | Only support Power bank charging model, not support power pass-through model |
| E14 AMD 3rd Generation- 20YF - E14 AMD Gen 3 | 20YF | Only support Power bank charging model, not support power pass-through model |
| E14-IML-20RA MT | 20RA | Only support Power bank charging model, not support power pass-through model |

| | | |
|---|------|--|
| E14-IML-20RB MT | 20RB | Only support Power bank charging model, not support power pass-through model |
| E15 2nd Generation-ARE-20T8 MT 2020 | 20T8 | |
| E15 2nd Generation-ARE-20T9 MT 2020 | 20T9 | |
| E15 AMD 3rd Generation-20YG - E15 AMD Gen 3 | 20YG | Only support Power bank charging model, not support power pass-through model |
| E15 AMD 3rd Generation-20YH - E15 AMD Gen 3 | 20YH | Only support Power bank charging model, not support power pass-through model |
| E15 AMD 3rd Generation-20YJ - E15 AMD Gen 3 | 20YJ | Only support Power bank charging model, not support power pass-through model |
| E15 AMD 3rd Generation-20YK - E15 AMD Gen 3 | 20YK | Only support Power bank charging model, not support power pass-through model |

| | | |
|---|------|--|
| E15 G2-20TD MT 2020 | 20TD | Only support Power bank charging model, not support power pass-through model |
| E15 G2-20TE MT 2020 | 20TE | Only support Power bank charging model, not support power pass-through model |
| E15-IML-20RD MT | 20RD | Only support Power bank charging model, not support power pass-through model |
| E15-IML-20RE MT | 20RE | Only support Power bank charging model, not support power pass-through model |
| E495-20NE MT | 20NE | |
| E595-20NF MT | 20NF | |
| IdeaPad Flex 3 CB 11M735- MT 82HG | 82HG | |
| IdeaPad Flex 5 14ALC05- 82HU - IdeaPad Flex 5 14ALC05 | 82HU | Only support Power bank charging model, not support power pass-through model |

| | | |
|---|------|--|
| IdeaPad Flex 5 14IIL05-MT 81WS | 81WS | Only support Power bank charging model, not support power pass-through model |
| IdeaPad Flex 5 14IIL05-MT 81X1 | 81X1 | Only support Power bank charging model, not support power pass-through model |
| IdeaPad Flex 5 14ITL05- 82HS - IdeaPad Flex 5 14ITL05 | 82HS | |
| IdeaPad Flex 5 15ALC05- 82HV - IdeaPad Flex 5 15ALC05 | 82HV | Only support Power bank charging model, not support power pass-through model |
| IdeaPad Flex 5 15IIL05-MT 81X3 | 81X3 | Only support Power bank charging model, not support power pass-through model |

| | | |
|---|------|--|
| IdeaPad Flex 5 15ITL05- 82HT - IdeaPad Flex 5 15ITL05 | 82HT | |
| IdeaPad Slim 7 14ARE05-MT 82A5 | 82A5 | |
| IdeaPad Slim 7 14ITL05-MT 82A6 | 82A6 | Only support Power bank charging model, not support power pass-through model |
| IdeaPad Slim 7 15IIL05-MT 82AD | 82AD | |
| IdeaPad Slim 7 15ITL05-MT 82AF | 82AF | Only support Power bank charging model, not support power pass-through model |
| L13 Clam 2nd Generation- 20VH MT 2020 | 20VH | Only support Power bank charging model, not support power pass-through model |

| | | |
|--|------|--|
| L13 Clam 2nd Generation- 20VJ MT 2020 | 20VJ | Only support Power bank charging model, not support power pass-through model |
| L13 Clam-20R3 MT | 20R3 | |
| L13 Clam-20R4 MT | 20R4 | |
| L13 Yoga 2nd Generation- 20VK MT 2020 | 20VK | Only support Power bank charging model, not support power pass-through model |
| L13 Yoga 2nd Generation- 20VL MT 2020 | 20VL | Only support Power bank charging model, not support power pass-through model |
| L13 Yoga-20R5 MT | 20R5 | |
| L13 Yoga-20R6 MT | 20R6 | |
| L14 AMD G1-20U5 MT 2020 | 20U5 | |

| | | |
|--------------------------------|------|--|
| L14 AMD G1-20U6 MT 2020 | 20U6 | |
| L14 AMD G2-20X5 - L14 Gen 2 | 20X5 | Only support Power bank charging model, not support power pass-through model |
| L14 AMD G2-20X6 - L14 Gen 2 | 20X6 | Only support Power bank charging model, not support power pass-through model |
| L14 G2-20X1 - L14 Gen 2 | 20X1 | Only support Power bank charging model, not support power pass-through model |
| L14 G2-20X2 - L14 Gen 2 | 20X2 | Only support Power bank charging model, not support power pass-through model |
| L15 AMD G1-20U7 MT 2020 | 20U7 | |
| L15 AMD G1-20U8 MT 2020 | 20U8 | |
| L15 AMD G2-20X7 - L15 Gen 2 | 20X7 | Only support Power bank charging model, not support power pass-through model |

| | | |
|---|------|--|
| L15 AMD G2-20X8 - L15 Gen 2 | 20X8 | Only support Power bank charging model, not support power pass-through model |
| L15 G2-20X3 - L15 Gen 2 | 20X3 | Only support Power bank charging model, not support power pass-through model |
| L15 G2-20X4 - L15 Gen 2 | 20X4 | Only support Power bank charging model, not support power pass-through model |
| Lenovo 100e 2nd Gen-82GJ MT 2020 | 82GJ | Only support Power bank charging model, not support power pass-through model |
| Lenovo 100e Chromebook 2nd Gen AST-82CD MT 2020 | 82CD | |
| Lenovo 100e Chromebook 2nd Gen AST_BRL-82LS MT 2020 | 82LS | |
| Lenovo 100e Chromebook 2nd Gen MTK-81QB MT | 81QB | |

| | | |
|--|------|--|
| Lenovo 10e Chromebook Tablet-82AM MT 2020 | 82AM | |
| Lenovo 10e Chromebook Tablet-82AQ MT 2020 | 82AQ | |
| Lenovo 14w-81MQ MT | 81MQ | |
| Lenovo 300e 2nd Gen-82GK MT 2020 | 82GK | |
| Lenovo 300e Chromebook 2nd Gen AST-82CE MT 2020 | 82CE | |
| Lenovo 300e Chromebook 2nd Gen MTK-81QC MT | 81QC | |
| Lenovo Chromebook C330- MT 81HY | 81HY | |

| | | |
|--|------|--|
| Lenovo Chromebook S330- MT 81JW | 81JW | |
| Lenovo IdeaPad S540-13ITL- MT 82H1 | 82H1 | Only support Power bank charging model, not support power pass-through model |
| Lenovo IdeaPad S940- 14IWL-MT 81R0 | 81R0 | Only support Power bank charging model, not support power pass-through model |
| Lenovo ThinkBook 13s-IML- MT 20RR | 20RR | |
| Lenovo ThinkBook 14s Yoga ITL-MT 20WE | 20WE | |
| Lenovo ThinkBook 14s-IML- MT 20RS | 20RS | |
| Lenovo Yoga C940-14IIL-MT 81Q9 | 81Q9 | |

| | | |
|--------------------------------------|------|--|
| Lenovo Yoga S730-13IML- MT 81U4 | 81U4 | |
| Lenovo Yoga S940-14IWL- MT 81Q7 | 81Q7 | Only support Power bank charging model, not support power pass-through model |
| P14s 2nd Generation-20VX MT 2021 | 20VX | Only support Power bank charging model, not support power pass-through model |
| P14s 2nd Generation-20VY MT 2021 | 20VY | Only support Power bank charging model, not support power pass-through model |
| P14s AMD G2-21A0 - P14s AMD Gen 2 | 21A0 | |
| P14s AMD G2-21A1 - P14s AMD Gen 2 | 21A1 | |
| P15s 1st Generation-20T4 MT 2020 | 20T4 | |

| | | |
|--|------|--|
| P15s 1st Generation-20T5 MT 2020 | 20T5 | |
| P15s 2nd Generation-20W6 - P15s Gen 2 | 20W6 | Only support Power bank charging model, not support power pass-through model |
| P15s 2nd Generation-20W7 - P15s Gen 2 | 20W7 | Only support Power bank charging model, not support power pass-through model |
| P43s-20RH MT | 20RH | |
| P43s-20RJ MT | 20RJ | |
| P53s-20N6 MT | 20N6 | |
| P53s-20N7 MT | 20N7 | |
| T14 2nd Generation-20W0 MT 2021 | 20W0 | Only support Power bank charging model, not support power pass-through model |

| | | |
|---------------------------------------|------|--|
| T14 2nd Generation-20W1 MT 2021 | 20W1 | Only support Power bank charging model, not support power pass-through model |
| T14 2nd Generation-20W2 MT 2021 HC | 20W2 | Only support Power bank charging model, not support power pass-through model |
| T14 2nd Generation-20W3 MT 2021 HC | 20W3 | Only support Power bank charging model, not support power pass-through model |
| T14 AMD G1-20UD MT 2020 | 20UD | |
| T14 AMD G1-20UE MT 2020 | 20UE | |
| T14 AMD G2-20XK - T14 AMD Gen 2 | 20XK | Only support Power bank charging model, not support power pass-through model |
| T14 AMD G2-20XL - T14 AMD Gen 2 | 20XL | Only support Power bank charging model, not support power pass-through model |

| | | |
|--|------|--|
| T14s 2nd Generation-20WM - T14s Gen 2 | 20WM | Only support Power bank charging model, not support power pass-through model |
| T14s 2nd Generation-20WN - T14s Gen 2 | 20WN | Only support Power bank charging model, not support power pass-through model |
| T14s AMD G1-20UH MT 2020 | 20UH | |
| T14s AMD G1-20UJ MT 2020 | 20UJ | |
| T14s AMD G2-20XF - T14s AMD Gen 2 | 20XF | Only support Power bank charging model, not support power pass-through model |
| T14s AMD G2-20XG - T14s AMD Gen 2 | 20XG | Only support Power bank charging model, not support power pass-through model |
| T15 2nd Generation-20W4 - T15 Gen 2 | 20W4 | Only support Power bank charging model, not support power pass-through model |

| | | |
|---|------|--|
| T15 2nd Generation-20W5 - T15 Gen 2 | 20W5 | Only support Power bank charging model, not support power pass-through model |
| T15g G2-20YS - T15g Gen 2 | 20YS | Only support Power bank charging model, not support power pass-through model |
| T15g G2-20YT - T15g Gen 2 | 20YT | Only support Power bank charging model, not support power pass-through model |
| ThinkBook 13x ITG-20WJ - ThinkBook 13x ITG | 20WJ | |
| ThinkBook 14 2nd Generation-ARE-MT 20VF | 20VF | Only support Power bank charging model, not support power pass-through model |
| ThinkBook 14 2nd Generation-ITL-MT 20VD | 20VD | |
| ThinkBook 14 3rd Generation - ACL-MT 21A2 ThinkBook 14 G3 ACL | 21A2 | Only support Power bank charging model, not support power pass-through model |

| | | |
|---|------|--|
| ThinkBook 14 G3 ITL-21A3 - ThinkBook 14 G3 ITL | 21A3 | |
| ThinkBook 15 2nd Generation-ARE-MT 20VG | 20VG | Only support Power bank charging model, not support power pass-through model |
| ThinkBook 15 2nd Generation-ITL-MT 20VE | 20VE | |
| ThinkBook 15 3rd Generation - ACL-MT 21A4 ThinkBook 15 G3 ACL | 21A4 | Only support Power bank charging model, not support power pass-through model |
| ThinkBook 15 G3 ITL-21A5 - ThinkBook 15 G3 ITL | 21A5 | |
| ThinkPad 11e 6th Generation- 20SE MT | 20SE | Only support Power bank charging model, not support power pass-through model |

| | | |
|---|------|--|
| ThinkPad 11e 6th Generation- 20SF MT | 20SF | Only support Power bank charging model, not support power pass-through model |
| ThinkPad L14-20U1 MT 2020 | 20U1 | Only support Power bank charging model, not support power pass-through model |
| ThinkPad L14-20U2 MT 2020 | 20U2 | Only support Power bank charging model, not support power pass-through model |
| ThinkPad L15-20U3 MT 2020 | 20U3 | Only support Power bank charging model, not support power pass-through model |
| ThinkPad L15-20U4 MT 2020 | 20U4 | Only support Power bank charging model, not support power pass-through model |
| ThinkPad P14s-20S4 MT 2020 | 20S4 | |
| ThinkPad P14s-20S5 MT 2020 | 20S5 | |
| ThinkPad P15g-20UR MT 2020 | 20UR | Only support Power bank charging model, not support power pass-through model |

| | | |
|---------------------------------|------|--|
| ThinkPad P15g-20US MT 2020 | 20US | Only support Power bank charging model, not support power pass-through model |
| ThinkPad T14-20S0 MT 2020 | 20S0 | |
| ThinkPad T14-20S1 MT 2020 | 20S1 | |
| ThinkPad T14-20S2 MT 2020 HC | 20S2 | |
| ThinkPad T14-20S3 MT 2020 HC | 20S3 | |
| ThinkPad T14s-20T0 MT 2020 | 20T0 | |
| ThinkPad T14s-20T1 MT 2020 | 20T1 | |

| | | |
|--------------------------------------|------|--|
| ThinkPad T15-20S6 MT 2020 | 20S6 | |
| ThinkPad T15-20S7 MT 2020 | 20S7 | |
| X1 Carbon 5th Generation- 20HQ MT | 20HQ | Only support Power bank charging model, not support power pass-through model |
| X1 Carbon 5th Generation- 20HR MT | 20HR | Only support Power bank charging model, not support power pass-through model |
| X1 Carbon 5th Generation- 20K3 MT | 20K3 | Only support Power bank charging model, not support power pass-through model |
| X1 Carbon 5th Generation- 20K4 MT | 20K4 | Only support Power bank charging model, not support power pass-through model |
| X1 Carbon 6th Generation- 20KG MT | 20KG | Only support Power bank charging model, not support power pass-through model |

| | | |
|---|------|--|
| X1 Carbon 6th Generation- 20KH MT | 20KH | Only support Power bank charging model, not support power pass-through model |
| X1 Carbon 7th Generation- 20QD MT | 20QD | Only support Power bank charging model, not support power pass-through model |
| X1 Carbon 7th Generation- 20QE MT | 20QE | Only support Power bank charging model, not support power pass-through model |
| X1 Carbon 7th Generation- 20R1 MT | 20R1 | Only support Power bank charging model, not support power pass-through model |
| X1 Carbon 7th Generation- 20R2 MT | 20R2 | Only support Power bank charging model, not support power pass-through model |
| X1 Carbon 8th Generation- 20U9 MT 2020 | 20U9 | |
| X1 Carbon 8th Generation- 20UA MT 2020 | 20UA | |

| | | |
|---|------|--|
| X1 Carbon 9th Generation- 20XW - X1 Carbon Gen 9 | 20XW | Only support Power bank charging model, not support power pass-through model |
| X1 Carbon 9th Generation- 20XX - X1 Carbon Gen 9 | 20XX | Only support Power bank charging model, not support power pass-through model |
| X1 Extreme 2nd Generation- 20QV MT | 20QV | |
| X1 Extreme 2nd Generation- 20QW MT | 20QW | |
| X1 Fold-20RK MT 2020 | 20RK | Only support Power bank charging model, not support power pass-through model |
| X1 Fold-20RL MT 2020 | 20RL | Only support Power bank charging model, not support power pass-through model |
| X1 Nano-20UN MT 2020 | 20UN | |
| X1 Nano-20UQ MT 2020 | 20UQ | |

| | | |
|--|------|--|
| X1 Titanium G1-20QA MT 2020 | 20QA | |
| X1 Titanium G1-20QB MT 2020 | 20QB | |
| X1 Yoga 2nd Generation- 20JD MT | 20JD | Only support Power bank charging model, not support power pass-through model |
| X1 Yoga 2nd Generation- 20JE MT | 20JE | Only support Power bank charging model, not support power pass-through model |
| X1 Yoga 2nd Generation-20JF MT | 20JF | Only support Power bank charging model, not support power pass-through model |
| X1 Yoga 2nd Generation- 20JG MT | 20JG | Only support Power bank charging model, not support power pass-through model |
| X1 Yoga 3rd Generation- RAVEN-3.0 20LD MT | 20LD | Only support Power bank charging model, not support power pass-through model |

| | | |
|--|------|--|
| X1 Yoga 3rd Generation- RAVEN-3.0 20LE MT | 20LE | Only support Power bank charging model, not support power pass-through model |
| X1 Yoga 3rd Generation- RAVEN-3.0 20LF MT | 20LF | Only support Power bank charging model, not support power pass-through model |
| X1 Yoga 3rd Generation- RAVEN-3.0 20LG MT | 20LG | Only support Power bank charging model, not support power pass-through model |
| X1 Yoga 4th Generation- 20QF MT | 20QF | Only support Power bank charging model, not support power pass-through model |
| X1 Yoga 4th Generation- 20QG MT | 20QG | Only support Power bank charging model, not support power pass-through model |
| X1 Yoga 4th Generation- 20SA MT | 20SA | Only support Power bank charging model, not support power pass-through model |
| X1 Yoga 4th Generation- 20SB MT | 20SB | Only support Power bank charging model, not support power pass-through model |

| | | |
|---|------|--|
| X1 Yoga 5th Generation- 20UB MT 2020 | 20UB | |
| X1 Yoga 5th Generation- 20UC MT 2020 | 20UC | |
| X1 Yoga 6th Generation- 20XY - X1 Yoga Gen 6 | 20XY | Only support Power bank charging model, not support power pass-through model |
| X1 Yoga 6th Generation- 20Y0 - X1 Yoga Gen 6 | 20Y0 | Only support Power bank charging model, not support power pass-through model |
| X12 Detachable 1st Generation-20UV MT 2020 | 20UV | |
| X12 Detachable 1st Generation-20UW MT 2020 | 20UW | |
| X13 AMD G1-20UF MT 2020 | 20UF | |

| | | |
|--|------|--|
| X13 AMD G1-20UG MT 2020 | 20UG | |
| X13 AMD G2-20XH - X13 AMD Gen 2 | 20XH | Only support Power bank charging model, not support power pass-through model |
| X13 AMD G2-20XJ - X13 AMD Gen 2 | 20XJ | Only support Power bank charging model, not support power pass-through model |
| X13 G1-20T2 MT 2020 | 20T2 | |
| X13 G1-20T3 MT 2020 | 20T3 | |
| X13 G2-20WK - X13 Gen 2 | 20WK | |
| X13 G2-20WL - X13 Gen 2 | 20WL | |
| X13 Yoga 2nd Generation- 20W8 MT 2021 | 20W8 | Only support Power bank charging model, not support power pass-through model |

| | | |
|--|------|--|
| X13 Yoga 2nd Generation- 20W9 MT 2021 | 20W9 | Only support Power bank charging model, not support power pass-through model |
| X390-20Q0 MT | 20Q0 | |
| X390-20Q1 MT | 20Q1 | |
| X390-20SC MT | 20SC | |
| X390-20SD MT | 20SD | |
| X395-20NL MT | 20NL | |
| X395-20NM MT | 20NM | |
| Yoga 6 13ALC6-82ND - Yoga 6 13ALC6 | 82ND | Only support Power bank charging model, not support power pass-through model |

| | | |
|---|------|--|
| Yoga 6 13ARE05-MT 82FN | 82FN | Only support Power bank charging model, not support power pass-through model |
| Yoga 7 14ITL5-82LW - Yoga 7 14ITL5 | 82LW | Only support Power bank charging model, not support power pass-through model |
| Yoga 7 14ITL5-MT 82BH | 82BH | Only support Power bank charging model, not support power pass-through model |
| Yoga 7 15ITL5-MT 82BJ | 82BJ | Only support Power bank charging model, not support power pass-through model |
| Yoga Slim 7 13ACN5-82CY - Yoga Slim 7 13ACN5 | 82CY | Only support Power bank charging model, not support power pass-through model |
| Yoga Slim 7 13ITL5-MT 82CU | 82CU | Only support Power bank charging model, not support power pass-through model |
| Yoga Slim 7 14ARE05-MT 82A2 | 82A2 | |

| | | |
|---|------|--|
| Yoga Slim 7 14IIL05-MT 82A1 | 82A1 | |
| Yoga Slim 7 14ITL05-MT 82A3 | 82A3 | Only support Power bank charging model, not support power pass-through model |
| Yoga Slim 7 15IIL05-MT 82AA | 82AA | |
| Yoga Slim 7 15ITL05-MT 82AC | 82AC | Only support Power bank charging model, not support power pass-through model |
| Yoga Slim 7 Carbon 13ITL5- MT 82EV | 82EV | Only support Power bank charging model, not support power pass-through model |
| Yoga Slim 7 Pro 14ACH5 O- 82N5 - Yoga Slim 7 Pro 14ACH5 O | 82N5 | Only support Power bank charging model, not support power pass-through model |

| | | |
|---|------|--|
| Yoga Slim 7 Pro 14ACH5- 82MS - Yoga Slim 7 Pro 14ACH5 | 82MS | Only support Power bank charging model, not support power pass-through model |
| Yoga Slim 7 Pro 14IHU5 O- 82NH - Yoga Slim 7 Pro 14IHU5 O | 82NH | |
| Yoga Slim 7 Pro 14IHU5-82NC - Yoga Slim 7 Pro 14IHU5 | 82NC | |